



## 16 steps to ensure the successful use of **Basic Points** Alkorplan 2000® pool covering.

- 1 Overlap the sheet approximately 7 cm.
- 2 Puncture the sheet every 30-40 cm to avoid any slippage during fixing.
- 3 Use double soldering to ensure successful fixing.
- 4 Verify the effectiveness of the 2nd soldering by slowly passing a bodkin between the sheets to see if it stops at a point that remains unsoldered.
- 5 To fix the sheeting in the perimeter, use:  
A/ Laminated sheet (Metal sheet + PVC covering).  
B/ Profile (PVC guide to insert "9 mm band").
- 6 In case of an irregular base – unevenness, poor application, etc. – it is advisable to use a "Geotextile" between the base and the sheet.
- 7 Disinfect the base with "Alkorplus® 81052 " liquid treatment to avoid the formation of micro organisms later.
- 8 Improve waterproofing by impregnating all the soldering points with a PVC liquid.
- 9 Take the precaution of leaving at least 2 cm space on each side on the sheets placed at the bottom of the pool.
- 10 On the wall sheet mounted at the bottom, cut the sheet approximately 11cms from the internal angle.
- 11 Tighten 2cms towards the centre of the sheet mounted on the floor on each side – 'breaking'-
- 12 Mechanical fixing should be used in case of pronounced incline, on the upper sheets to avoid slippage.
- 13 Seal with neutral silicone in the space between the fixing and the corner stone.
- 14 Fill the pool with 40 cm of water before drainage and maintain until the sheeting is sufficiently tight to mount the other accessories (pumps, lights, skimmers, cleaners, etc.).
- 15 When the pool is renovated, always replace existing accessories with a double-jointed liner to ensure greater waterproofing and compatibility with sheet.
- 16 Avoid placing accessories on top of the solder.

